


# EP-820 Parts List

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	E800-01	Base Assembly	1
2	E800-01-C	Stabilizer	1
3	E800-01-D	Slotted Top Core	1
4	E800-02	Handle Grip	1
5	E800-03	Bottom Core	1
6	E800-04	"O" Ring	1
7	E820-06	Ball Handle Assembly	1



12/12/24 REV. B